

- 1- Make sure the parameter C8 is on "0"
- 2- Cut the power – then put the power on
- 3- Push the start button ( the system will still function in the "wrong" way )
- 4- Close the door manually
- 5- Hold the 4 buttons ( + / - / up / down )of the control keyboard for at least 3 seconds
- 6- On display you must have the 4 question marks ( instead of "OK" )
- 7- Push again the start button; the system will start initialization again to determinate the door opening side as well as the open and closed door maxi positions

Staying at your disposal for any further questions you may have.

Best regards

Luc Buys / Fermod Export



**FERMOD®**

75, rue de Richelieu - 75002 PARIS - FRANCE  
Tél. 33 (0)1 42 06 94 06 - Fax 33 (0)1 42 06 84 51  
<http://www.fermod.com> - e-mail: [contact@fermod.com](mailto:contact@fermod.com)